



NOZZLE TIP (SOAK IN ZEP, CLR OR VINEGAR)



NOZZLE IMPELLER (SOAK W/NOZZLE)



**ANTI-DRIP
SPRING &
BALL
(DO NOT SOAK)**



**DISASSEMBLE NOZZLE
TO CLEAN CLOGGING**



ANTI-DRIP BODY (DO NOT SOAK)

CLEAN CLOGGED NOZZLE BY REMOVING TIP & IMPELLER FROM ANTI-DRIP BODY